



PART #	DESCRIPTION	QTY	PART #	DESCRIPTION	QTY	PART #	DESCRIPTION	QTY
1	Upper Receiver Complete	1	29	Buffer Sleeve	1	57	Rear Hand Grip	1
2	M107A1 Cheek Piece	1	30	Buffer	1	58	Rear Hand Grip Screw	1
3	Cheek Piece Screw	3	31	Accelerator Rod	1	59	Lower Receiver Complete	1
4	Windage Knob Pin	1	32	Accelerator	1	60	Rear Lock Pin	2
5	Windage Knob	1	33	Bolt Extender	1	61	Safety	1
6	Rear Sight Assembly	1	34	Accelerator Spring	1	62	Safety Detent	1
7	Rear Sight Base Detent	1	35	Bolt Carrier Pin	3	63	Safety Detent Spring	1
8	Rear Sight Spring	1	36	Accelerator Spring Screw	1	64	Grip	1
9	Windage Screw Spring	1	37	Bolt Index Pin Retaining Pin	1	65	Pistol Grip Washer	1
10	Windage Screw	1	38	Bolt Index Pin	1	66	Pistol Grip Screw	1
11	Center Nut Plate	2	39	Bolt Carrier	1	67	Trigger Spring	1
12	Front Sling Loop	1	40	Sear Spring	1	68	Disconnecter Spring	1
13	10-32 x.50 BHCS	2	41	Sear Assembly	1	69	Trigger	1
14	Front Sight Catch Pin	1	42	Cocking Lever	1	70	Disconnecter	1
15	Front Sight Pin	1	43	Cocking Lever Spring	1	71	Transfer Bar Assembly	1
16	Front Sight Catch	1	44	Cam Pin Assembly	1	72	Magazine Catch	1
17	Front Sight	1	45	Cam / Ejector Pin	2	73	Magazine Catch Spring	1
18	Front Sight Spring	1	46	Firing Pin Assembly	1	74	Magazine Catch Pin	1
19	Barrel Spring Screw	4	47	Bolt	1	75	Trigger Pin	2
20	Barrel Key	1	48	Ejector Spring	1	76	Magazine Assembly	1
21	Barrel Spring	2	49	Ejector	1	77	Midlock Pin	1
22	Barrel Assembly	1	50	Extractor Spring	1	78	Bipod Assembly	1
23	Battery Bumper	1	51	Extractor Plunger	1	79	Yoke Mount	2
24	Barrel Impact Bumper	1	52	Extractor	1	80	Bipod Shim Bushing	2
25	Muzzle Brake Shim Kit	1	53	Recoil Pad Screw	2	81	Yoke Mount Washer	2
26	Muzzle Brake Screw	1	54	Recoil Pad	1	82	Yoke Mount Nut	2
27	Muzzle Brake	1	55	Monopod Lock Knob	1			
28	Main Spring	1	56	Monopod Assembly	1			